



Connection

Connection of addressable detectors IA, OA, TDT and EV-PP series:




G003132

Connection of addressable detectors NS, CN and EV-series** (EV-PP excluded):




G003133

Connection of conventional detectors DIS3, DOS3, HCI00, NS-DIR and NS-DUV:



G003134

Connection of conventional flame detectors EVC-IR (not NS-DIR or NS-DUV):



G003135

* All types of detectors do not have the remote output. Please refer to the data sheet for the detector in question.

** For loop units with short circuit isolators, see connection on data sheet for that unit.